

Mounting and Clamp

*PAB Clamp









Is designed for mounting SD-20 & SD-21 series sensors on 12 ~125 round(tie-rod) cylinder.
 PAB-01 : Short clamp , is designed 12 ~63 round(tie-rod)cylinder.
 PAB-02 : Long clamp , is designed 12 ~125 round(tie-rod)cylinder.

*PBS Clamp

Is designed for mounting SD-33 series sensors on 12 ~125 round(tie-rod) cylinder.
 PBS-01 : Short clamp , is designed 12 ~63 round(tie-rod)cylinder.
 PBS-02 : Long clamp , is designed 12 ~125 round(tie-rod)cylinder.







*PBT Clamp

Is designed for mounting SD-03 & SD-15 series sensors on 12 ~125 round(tie-rod) cylinder.
 PBT-01 : Short clamp , is designed 10 ~63 round(tie-rod)cylinder.
 PBT-02 : Long clamp , is designed 10 ~125 round(tie-rod)cylinder.

Step 1 Start by keeping screw 3 to 4 turns into barrel nut on the end of the band assembly	Step 2 Place the screw head into clamp slot and wrap the band around the cylinder, Position the pin with the nearest hole on the band and mark the hole with a permanent marker.	Step 3 Remove clamp assembly from the cylinder. Locate the marked hole that fits to the cylinder size , cut the band at midway between the next two adjacent hole.	Step 4 Insert cut of the band into a flat slot opposite from the clamp slot. Place the chosen hole over the pin and bend the band firmly down with thumb pressure. Then wrap the band around cylinder barrel and re-insert screw head into clamp. Position the switch and tighten.
			<p>Do not over tighten. Damage to the switch and/or cylinder may occur.</p> 
	<p>SD-20 SD-21</p>  <p>12~125</p> <p>*PAB Clamp</p>	<p>SD-33</p>  <p>10~125</p> <p>*PBS Clamp</p>	<p>SD-03 SD-15</p>  <p>10~125</p> <p>*PBT Clamp</p>

*PBK Clamp

Is designed for mounting SD-03 & SD-15 series sensors on 6 ~ 63 round cylinder.
 PBK-01 : Short clamp , is designed 6 ~40 round cylinder.
 PBK-02 : Long clamp , is designed 6 ~63 round cylinder.

	Step 1 Loosen screw & nut.	Step 2 Place sensor & wrap the band around the cylinder, Position the hook with the nearest hole on the band and mark the hole with a permanent marker.	Step 3 Remove mounting assembly. Cut the band at the nearest edge of next hole.	Step 4 Re-place the sensor & mounting assembly. Wrap the band & put the chosen hole on hook. Position the switch and tighten. Finally swivel nut for steadying.
				<p>SD-03 SD-15</p>  <p>6~63</p> <p>Do not over tighten. Damage to the switch and/or cylinder may occur.</p>